Programming Procedure

The Moxi remote allows you to access, control, and enjoy the many features of your media center..

The Moxi remote operates the media center, and—once programmed—will simultaneously control the volume and mute functions of your TV or audio device. The power button on the remote can turn on your TV and an audio device.

Use the tables on the opposite side of this pamphlet to find the codes for your brand of TV or audio device.

If your brand is not listed, or if the given codes do not work, follow the instructions in the Programming by Search section.

Programming a Third-Party Learning Universal Remote

Moxi remotes are built by Universal Electronics Incorporated (http://www.uei.com). The communication technology used by the remote is compatible with many universal remotes.

Replacing batteries

When replacing batteries, use only high-quality, non-corrosive batteries designed for use in electronic equipment.

Programming the TV by Code

Follow the steps below to program the remote to control power and volume for your TV.

1. Turn on the TV or audio device you want the to control.
2. On the Moxi remote, press and hold the **MOXI** and **OK** buttons simultaneously until the LED at the top of the remote blinks twice.
3. Using the number buttons on the remote, enter one of the codes for the TV from the reference tables (on the opposite side of this pamphlet). When you enter the correct code, the LED blinks twice. If it blinks once, the code was invalid—try another code.
4. Press the **Power** button on the remote.
5. If the TV does not respond, repeat steps 2 and 3 using another listed code. Repeat until successful, or use the Programming by Search procedure.

Older devices

Some older devices may not be supported. If the device still fails to respond, use its original remote to control it. Contact your cable provider's customer service for additional assistance.

Programming the TV and an audio device by Code

Follow the steps below to program the remote to control power for your TV as well as power and volume for an audio device.

1. Turn on the TV or audio device you want the to control.
2. On the Moxi remote, press and hold the **MOXI** and **OK** buttons simultaneously until the LED at the top of the remote blinks twice.
3. Using the number buttons on the remote, enter one of the codes for your device from the reference tables (on the opposite side of this pamphlet). When you enter the correct code, the LED blinks twice. If it blinks once, the code was invalid—try another code.
4. To program the remote to control a second device, hold the **MOXI** and **OK** buttons simultaneously until the LED at the top of the remote blinks twice.
5. Repeat Step 3 using the code for the audio device.
6. Press the **Power** button on the remote. If you programmed two devices, both turn off.
7. If the TV or audio device does not respond, repeat steps 2 and 3 using another listed code. Repeat until successful, or use the Programming by Search procedure.

Programming by Search

If your TV or audio device is not listed or does not respond to the codes listed, try programming by search. Programming by search allows the remote to cycle through codes to find one that works with your TV or audio device.

1. Turn on the TV or audio device you want the remote to control.
2. On the Moxi remote, press and hold the **MOXI** and **OK** buttons simultaneously until the LED at the top of the remote blinks twice.
3. Using the number buttons on the remote, press **9 9 1 0** for TV, or **9 9 1 1** for audio device. The LED light blinks twice.
4. Press the **Mute** button.
   - If this mutes the device, go to step 5.
   - If this does not mute the device, press the **up** arrow to advance to the next code, and then press **Mute** again. Repeat until the device responds.
5. Press **OK** to set the current code and finish.

Resetting to factory default

To reset the remote to the original factory setting, enter code **9 9 9 9**, and then press **OK** in step 3.

ticker displays and hides Moxi Ticker

***/buy** locks and unlocks the Ticker (buy reserved for future use)

info displays additional information

ok selects or activates item in center focus

back shows last note page or jumps back 15 minutes

MOXI displays and hides Moxi Menu

replay jumps back seven seconds

pause pauses live or recorded shows and DVDs

rec starts the recording process

vol changes TV or receiver volume

jump goes to channel last viewed

clear deletes all entered text and recorded shows, hides screen overlays (Ticker, Flip Bar)

power turns TV/audio receiver on and off

VOD/On Demand launches On Demand menu (VOD/On Demand) or Moxi Menu (Guide)

live TV displays full-screen live TV

zoom toggles between full-screen media and Moxi Menu

arrows move through Moxi Menu

next shows next note page or jumps ahead 15 minutes

skip jumps ahead in buffered or recorded content

rew/fwd provides multi-speed (3x, 15x, 60x) reverse or forward video playback

mute toggles sound on and off

ch/page changes channels or pages through vertical menu

numbers provide direct channel tuning or phone-like text entry

enter applies numeric or text entries

000-0000-RI-DGO
© 2005 Digeo, Inc. All rights reserved. (October 2005)

TV Codes

Brand	Code
Abex	0032
Admiral	0093, 1463
Advent	0761, 1933, 0150
Adventura	0046
Aiko	0092
Aiwa	0701, 1914
Akai	0030, 1903, 0098, 0672
Alaron	0179, 0183
Albatron	0003, 0843
Ambassa-dor	0177
America Action	0180
Ampro	0751
Anam	0068, 0004, 0180, 0003
Anam National	0161, 0055
AOC	0003, 0030, 0137, 0185
Apex Digital	0148, 0879, 0748, 0890
Archer	0003
Audiovox	0092, 0180, 0802, 0875, 1951, 1937, 1952, 0003,1661
Aventura	1271
Axion	1937
Bell & Howell	0154
BenQ	1212, 1032
Bradford	0180
Brilliant	1007
Broksonic	1935, 0003, 0236, 1463, 1905, 1911, 1929
Candle	0186, 0046, 0030, 0056
Carnivale	0030
Carver	0054, 0170
Casio	1205
CCE	0217, 0329
Celebrity	0000
Celera	0148
Chang-hong	0148
Citizen	0186, 0046, 0056, 0030, 0032, 0060, 0092, 0280,1909
Clairtone	0185
Clarion	0180
Colt	1906
Commer-cial Solutions	0047
Concerto	0056
Contec	0158, 0036, 0180, 0185
Craig	0180, 0161

TV Codes

Brand	Code
Crosley	0054
Crown	0032, 0180
Curtis Mathes	0060, 0030, 0032, 0047, 0054, 0056, 0093, 0145, 0154, 0166, 1661, 0466, 1903, 1919
CXC	0180
Daewoo	0092, 1909, 1661, 0661, 0032, 0066, 0067, 0672
Dell	1080, 1178
Denon	0145, 0511
Dumont	0017
Durabrand	1271, 1463, 0003, 1178, 0180, 1034
Dwin	0093, 0774
Elec-troband	0000, 0185
Elec-trograph	1755
Electro-home	0032, 0036
Elektra	0017, 1661
Emerson	0236, 0180, 1178, 0179, 0177, 1463, 0282, 1911, 0270, 1944, 1909, 0280, 0183, 0181, 0158, 0032, 0185, 0036, 1905, 1271, 1909, 1929, 0154
Envision	0813, 0030
Epson	1122, 0833, 0840
ESA	1271, 1903
Fisher	0154
Fujitsu	0809, 0179, 0683, 0853
Funai	1271, 0180, 0179, 1271, 1904, 1944
Futuretech	0180
Gateway	1755, 1032
GE	0021, 0027, 0047, 0055, 1178, 0051, 0251, 1661, 0135, 0138, 0174, 0279, 0282, 1907, 1917, 1919, 1922
Gibralter	0017, 0030
Go Video	0886
GoldStar	0001, 0030, 1178, 0032, 1926
Goodmans	0360
Gradiente	0392

TV Codes

Brand	Code
Grunpy	0179, 0180
Haier	1034
Hallmark	1178
Harley Davidson	0043, 0179, 1904
Harman/ Kardon	0078, 0054
Harvard	0068, 0180
Havermy	0093
Helios	0865
Hello Kitty	1661
Himitsu	0180
Hisense	0748
Hitachi	0145, 0032, 0056, 0413, 0095, 0173, 0227, 0279, 0797, 1904, 0145
Hyundai	0849, 1219
Infinity	0054
InFocus	1164
Insignia	1204
Inteq	0017
IX	0877
Janeil	0046
JBL	0054
JCB	0000
Jensen	0050, 0761, 1933, 0150
JVC	0053, 0731, 0036, 0160, 0036, 1923
Kawasho	0158, 0308
KEC	0180
Kenwood	0030
KLH	0148, 1962
Kloss	0024, 0046, 0078
Konka	0707, 0632, 1939, 0180, 0638, 1939
KTV	0180, 0185, 0280, 0217, 0030, 0032, 0183
LG	1178, 0442, 0003, 0856, 1934
Lloyd's	1904
Loewe	0136
Luce	1031
Luxman	0056
LXI	0154, 0047, 0054, 0148, 1178
Magna-sonic	1913, 1909
Magnavox	0054, 0187, 1944, 0024, 0020, 1198, 1913, 0028, 0030, 0036, 0179, 0186, 0032, 0706, 1904, 1931
Magnin	1907

TV Codes

Brand	Code
Marantz	0054, 1154, 0704, 0854, 0030, 0444
Matsu-shita	0250, 0650
Maxent	1755
Mega-power	0003
Megatron	0003, 0145, 1178
MEI	0185
Memorex	0179, 1463, 1911, 1178, 1920, 0150, 0154, 1924, 1926, 1924
MGA	0150, 0030, 1178, 1907
Midland	0017, 0032, 0047, 0051, 0135
Minutz	0021
Mitsubishi	0150, 1178, 0014, 0093, 0358, 0868, 0098, 1917
Monivision	0003, 0843
Motorola	0055, 0093
MTC	0060, 0030, 0185, 0056
Multitech	0180, 0217
NAD	0148, 1178
NEC	0030, 0497, 1704, 0036, 0170, 0882, 0056, 0434
NetTV	1755
Nikko	1178, 0032, 0030, 0092
Noblex	0430
Norcent	0824, 0748
NTC	0092
Onwa	0180
Optimus	0250, 0166, 1924, 1913, 0154, 0650
Optoma	0887
Optonica	0093, 0165
Orion	1911, 0179, 0236, 1463, 1905, 1929
Panasonic	0051, 0250, 0650, 0055, 1924, 0226, 1941, 1410, 1947, 0162, 0375, 1919, 1946
Penney	0047, 0060, 0030, 0021, 0027, 0135, 1178, 0001, 0051, 0032, 0309, 1926, 1919, 1907, 0148, 0149, 0138, 0110, 0032, 0003

TV Codes

Brand	Code
Philco	0020, 0028, 0030, 0054, 0302
Philips	0054, 1961, 0690, 1154
Pilot	0030, 0032
Pioneer	0166, 1260, 0679, 0172
Polaroid	1276
Portland	0032, 0092
Prima	0761, 1933, 0150
Princeton	0717, 0003
Prism	0051
Proscan	0047, 1922
Proton	0466, 0003, 1178, 0031
Pulsar	0017
Quasar	0051, 0055, 0250, 0165, 0219, 0650, 1919, 1924
Radio-Shack	0165, 0180, 0030, 1178, 0032, 0154, 1904, 1920, 0047, 0056
RCA	0047, 0679, 1922, 0135, 1948, 1958, 0090, 0174, 1907, 1917, 1919
Realistic	0165, 0180, 0154, 0030, 0032, 1178, 0056
Rhapsody	0183, 0185
Runco	0497, 0603, 0017, 0251, 0030
Sampo	1755, 0030, 0032, 0100, 0110
Samsung	1903, 0060, 1178, 0766, 1959, 1903, 0030, 0032, 0056, 0329, 0302, 0427
Samsux	0032
Sansui	1911, 1935, 1463, 1904, 1929
Sanyo	0799, 0154, 0893, 0088, 0107, 0232, 1142, 1907
Scotch	1178
Scott	0236, 0309, 1178, 0179, 0180

TV Codes

Brand	Code
Sears	0154, 0148, 1007, 0047, 0054, 0056, 0149, 0168, 1271, 1178, 0179, 0032, 1904, 1926
Sharp	0093, 0165, 0491, 0153, 0851, 0032, 1917, 0036, 0220, 0032, 0398
Sharper Image	1950
Sheng Chia	0093
Simpson	0186, 0187
Solarism	1220
Sony	0000, 0353, 0834, 1904, 1925
Sounde-sign	1178, 0179, 0180, 0186
Sova	1952
Spectricon	0003, 0137
Square-view	1271
SSS	0180
Starlite	0180
Studio Experience	0843
Superscan	0864
Supre-Macy	0046
Supreme	0000
SVA	0587, 0748, 0865, 0871, 0872
Sylvania	0020, 0054, 1271, 0028, 1944, 0030, 0065, 0036, 1931, 1944
Symphonic	1271, 1913, 0180, 1904
Syntax	1144, 1178
Tandy	0093
Tatung	0003, 0055, 0396, 1032
Technics	0051, 0250
Technol Ace	0179
Techview	0847
Techwood	0003, 0051, 0056
Teknika	0186, 0054, 0179, 0180, 0032, 0092, 0056, 0060, 0150, 0175
Telefunken	0056, 1903
Tera	0031
Thomas	1904
TMK	0056, 0177, 1178
TNCi	0017

TV Codes

Brand	Code
Toshiba	0148, 0149, 0060, 1704, 1918, 0650, 0832, 1164, 1178, 1918, 1935, 0036, 0154, 1918
Tosonic	0185
Totevision	0032
Trical	0036
TVS	1463
Ultra	0391
Universal	0027
Vector Research	0030
VEOS	1007
Victor	0053
Vidikron	0242, 0054
Vidtech	0036, 1178
Viewsonic	0864, 0857, 0885, 1755
Viking	0046
Vizio	1032, 0864, 0885
Wards	0054, 0165, 1178, 0020, 0000, 0021, 0027, 0028, 0030, 0056, 0174, 0179, 0202
Waycon	0148
Westing-house	0889, 0890
White Westing-house	1909, 1463
Yamaha	0797, 0833, 0769, 0030, 0769
Zenith	0017, 1178, 1909, 1911, 0092, 1463, 1904, 1929
Zonda	0003

Receiver and Amplifier Codes

Brand	Code
Acurus	3765
Adcom	3002, 3304, 3616, 4616, 4617
Adcom	3577, 4100
Admiral	3182
Aiwa	3121, 3125, 3158, 3189, 3405, 3406, 4089, 4243, 4405, 4641
Akai	3076, 3224, 4255, 4512
Alco	4390
Amphion Media Works	4563, 4615
Amplifier Technolo-gies	4584
AMW	4563, 4615
Anam	4074, 4609
Apex Digital	4257, 4430, 4774
Arcam	4120
Audio-Source	3011
Audiotro-nic	4189
Audiovox	4390, 4627
B & K	3840
Bel Canto Design	4583, 4584
Biamp	3582
Bose	3639, 3674, 4229, 4253
Brix	4602
Cam-bridge Sound-works	4370
Capetronic	3531
Carver	3008, 3042, 3189, 3269, 3360, 3412, 4089, 4189
Casio	3195, 3201
Clarinette	3195
Classe	3733, 4461, 4462
Classic	4352
Coby	4263, 4389
Criterion	4420
Curtis Mathes	3080, 3201, 3300
Daewoo	4250
Dell	4383
Delphi	4414
Denon	3004, 3160, 3273, 3771, 4104, 4142, 4360

Receiver and Amplifier Codes

Brand	Code
Digital Audio Control	3085
Durabrand	4561
Elan	3647
Emerson	3255, 3424
Fisher	3042, 3219, 3360, 4801
Forte	3606
Fosgate	3111
Fosgate	4487
Garrard	3146, 3281, 3424, 3440, 3463, 3744
Gateway	4517, 4567
GE	3078
GE	3260
Glory Horse	4263
Go Video	4532
GoldStar	3031
GPX	3744
Hafler	3146
Harman/ Kardon	3106, 3892
Harman/ Kardon	3110, 3189, 3891, 4306
Hewlett Packard	4181
Hitachi	3228, 4273, 4801
Initial	4426
Inkel	3062, 3066
Integra	3135, 4298, 4320
JBL	3110, 3281, 4306
JVC	3331
JVC	3074, 3464, 4263, 4374, 4495, 4811
Kansai	3440
Kenwood	3297, 3356
Kenwood	3027, 3042, 3077, 3186, 3239, 3313, 3314, 4027, 4051, 4313, 4569, 4570
KLH	4390, 4412, 4428, 4664
Koss	3255, 3424, 3744, 4366, 4497
Lasonic	4798
Left Coast	3892
Lenoxx	4561
Lenoxx	4437
Lexicon	4802
Lexicon	4076
LG	4293
Linn	3269, 3282
Linn	3189

Receiver and Amplifier Codes

Brand	Code
Liquid Video	4497
Lloyd's	3195
Logitech	4408
Luxman	3165
Luxman	3149
LXI	3181, 3744
Magnavox	3269
Magnavox	3128, 3189, 3195, 3204, 3222, 3364, 3391, 3531, 4089, 4189, 4269, 4514
Marantz	3006, 3039, 3128, 3189, 3269, 3321, 3412, 3892, 4089, 4189, 4269, 4289
Mark Levinson	4483
McIntosh	3251
MCS	3039, 3201, 3346
Mitsubishi	4393
Modulaire	3195
Music-magic	4089
NAD	3320
Naim	3552
Nakamichi	3097, 3321, 3347, 4555
NEC	3131, 3264
Norcent	4389
NTDE Geniesom	3744
Onkyo	3119, 3135, 3380, 3842, 4298, 4320, 4531
Optimus	3042, 3080, 3177, 3181, 3186, 3219, 3300, 3395, 3440, 3531, 3622, 3670, 3738, 3744, 3801, 3823, 4023, 4074
Orient Power	3744
Oritron	4366, 4497
Outlaw	4487
Panasonic	3039, 3308, 3309, 3367, 3518, 3521, 4288, 4316, 4518, 4548, 4633, 4763, 4764
Parasound	3246
Penney	3195, 3201
Philco	4390

Receiver and Amplifier Codes

Brand	Code
Philips	3189, 3269, 3391, 3412, 3642, 3892, 4089, 4120, 4189, 4266, 4269
Pioneer	3013, 3080, 3150, 3244, 3289, 3300, 3531, 3630, 3823, 4023, 4384
Polaroid	4508
Polk Audio	3189, 3269, 3892, 4289
Proscan	4254
Quasar	3039
Radio-Shack	3744, 4263
RCA	3054, 3080, 3300, 3346, 3360, 3530, 3531, 3823, 4023, 4074, 4154, 4254, 4390, 4511, 4609
Realistic	3163, 3181, 3182, 3195, 3395
Regent	4437
Rio	4383, 4869
Saba	4519
Samsung	4295, 4500
Sansui	3189, 3193, 3321, 3323, 3346, 3593, 3623, 3652, 4089
Sanyo	3219, 3801, 4251, 4469
Schneider	3364
Scott	3105, 3163, 3322, 3390
Sears	3201
Sharp	3186, 3226, 3262, 4286
Sharper Image	4263, 4556
Sherwood	3062, 3066, 3475, 3491, 3502, 3565, 4077, 4423, 4653
Shinsonic	4426
Shure	3264
Sonic	3281
Sonic Blue	4383, 4532, 4869

Receiver and Amplifier Codes

Brand	Code
Sony	3158, 3168, 3220, 3415, 3689, 3815, 4058, 4126, 4158, 4258, 4349, 4406, 4441, 4442, 4558, 4658, 4758, 4759, 4822, 4858
Sounde-sign	3078, 3211, 3670
Sound-stream	3141
Stereo-phonics	4023
Sunfire	3313, 3314, 4313
Sylvania	3222
Symphonic	3182
Tandberg	3204, 3206
Teac	3163, 3387, 3463, 4074, 4267, 4390, 4528
Technics	3308, 3372, 3374, 3521
Technics	3039, 3208, 3309, 3518, 4308, 4309, 4518
Techwood	3281, 3344, 3364
Thorens	4189
Toshiba	3353
Venturer	4390
Victor	3331
Victor	3074
Wards	3013, 3078, 3211
Wards	3054, 3080, 3158, 3189
Welton	3344
Yamaha	3133, 3143, 3354, 3504
Yamaha	3081, 3082, 3176, 3186, 4176, 4276, 4331, 4375
Yorx	3195
Zenith	3281, 3622, 3744, 3857, 4293

Remote Control Programming and Use Instructions

moxi™ by digeo